

Sometimes your computer might show a blue or black screen when starting up because it has reverted to displaying on only one screen, usually the one it thinks is the main monitor.

When this happens, your other screen stays blank, which can make it look like something is wrong.

What can I do to fix this?


First, please ensure your projector is **switched on**.

Press **Windows key + P** on your keyboard.



A menu will appear on the right side of your screen.

Select **Duplicate** on the menu



Your screen will then be set to duplicate, meaning the image you see on your computer screen, will also show on your projector.